
Digital Projector
Quick Start Guide


Gaming Projector | X3100i / X3100

BenQ PN: 4J.JS901.006_V2.02

© 2026 BenQ Corporation. All rights reserved. Rights of modification reserved.



a




b



QS02
(Availability varies by region)

c




d

Quick start guide

Regulatory statements

Warranty card (varies by region)




Adjustment feet kit (for upside down projection)

HDMI™ HIGH-DEFINITION MULTIMEDIA INTERFACE
(For models with HDMI inputs)


PN: 4J.70L01.001


Setup

1




2







3 (Required only for models with QS02)



4



5



6




Image adjustments

Image zoom








Image focus





Lens shift






Projector placement

BenQ (gaming) projector calculator

Gaming projector calculator


Projector calculator




Ceiling mount guide

Video connection

1



2




Source

HDMI-1

HDMI-2

Now, game is on!

Get Awed by Details





Chat with BenQ

Support.BenQ.com

Warranty Information

Online Manual

X3100 SettingXchange

Product Support

Software Download

SettingXchange